3-in-1 Executive Style Pen: Laser Pointer, Ink Pen, and USB Flash Drive

Quick Guide:

I. Key Definition

A: Pen   D: Click to Use Laser Pointer

B: Ink Refill   E: Battery

C: USB   F: Laser Pointer

II. Pen Operation
1.   Pen writes at location "A."
2.   To change ink, pull "B" down.

III. USB Operation
1.   To use USB, pull "C" down.

IV. Laser Pointer Operation
1.   Click button at location "D" to use laser pointer.
2.   Laser points at location "F."

V. Battery
1.   Right twist location "E" to change battery.
2.   Change all batteries to ensure optimal performance

VI. Specification

- Built-in Memory: 1GB
- Interface: USB 1.1 and USB 2.0
- Dimension: 142mm x 16.5mm x 16.5mm

- Data Retention: 10 years
- Hot Plug & Play: Yes
- Password Protection: Yes

Note: Specifications subject to change without prior notice

For your Pictures/Video   For your Data   For your Music

For more information contact:
Tel: (905) 764-6200
Toll Free: (866) 370-5005